JUMO GmbH & Co. KG

Phone: Fax: e-mail: Internet:

Delivery address:Mackenrodtstraße 14. 36039 Fulda, Germany Postal address: 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex CM 20 2TT, UK Phone: +44 1279 635533 +44 1279 635262 Fax: e-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO PROCESS CONTROL INC. 885 Fox Chase, Suite 103 Coatesville PA 19320, USA 610-380-8002 Phone: 1-800-554-JUMO 610-380-8009 Fax: e-mail: info@JumoUSA.com Internet: www.JumoUSA.com



for stock items

Data Sheet 70.7030 (95.6530) Page 1/10

# JUMO dTRANS T03 J, B, T **Analog 2-wire transmitter** with digital adjustment

# JUMO dTRANS T03 BU, TU **Analog 3-wire transmitter** with digital adjustment

for connection to Pt100 resistance thermometers for installation in: - terminal head Form B to DIN 43 729 - terminal head Form J

for mounting on: - rail

# **Brief description**

These transmitters are designed for industrial applications and are used to measure the temperature through Pt100 resistance thermometers in 2-/3-wire circuit connections. The 4 - 20 mA or 0 - 10 V output signal is linear with temperature.

The continuous analog signal path enables an extremely fast reaction time of the output to a change in temperature (continuous analog measurement instead of digital sampling rate), resulting in a low-noise output signal that is insensitive to interference. A very high degree of precision - even with small ranges - is ensured thanks to the range-specific gain adjustment.

Digital communication allows the transmitter to be adapted to the measurement task (range, probe break and fine calibration).

Two versions are available to suit specific requirements:

### Instruments with basic type extension 880/990 (adjustable)

The transmitters are calibrated for a fixed range but can, at any time, be calibrated for a different range through the PC setup program.

Instruments with basic type extension 881/991 (configurable)

The required range can be configured through the PC setup program, without sensor simulation and measurement.

# **Overview of function**

	dTRANS T03 J Type 707030/	dTRANS T03 B Type 707031/	dTRANS T03 T Type 707032/	dTRANS T03 BU Type 707033/	dTRANS T03 TU Type 707034/
Input	Pt100	Pt100	Pt100	Pt100	Pt100
Connection circuit	2-wire	2-/ 3-wire	2-/ 3-wire	2-/ 3-wire	2-/ 3-wire
Mounting	terminal head Form J	terminal head Form B	rail	terminal head Form B	rail
Output	4 — 20mA	4 — 20mA	4 — 20mA	0 — 10V	0 — 10V



dTRANS T03 J Type 707030/...



dTRANS T03 B Type 707031/...



dTRANS T03 BU Type 707033/...



dTRANS T03 T Type 707032/...

dTRANS T03 TU Type 707034/...

# Technical data for 2-wire transmitter (Types 707030/..., 707031/... and 707032/...)

### Input for resistance thermometer

	dTRANS T03 J	dTRANS T03 B	dTRANS T03 T
	Туре 707030/	Type 707031/	Type 707032/
Measurement input	Pt100 (EN 60 751)		
Range limits		-200 to +850°C	
Connection circuit	2-wire circuit	2-/3-wire circuit	2-/3-wire circuit
Smallest span		25°C	
Largest span	1050°C		
Unit	°C or °F		
Zero shift	for spans < 75°C fixed zero: -40°C, -20°C, 0°C, 20°C, 40°C		
	for span 75°C: ±50°C		
	for spans > 75°C: see "Range organization" on page 7		
Sensor lead resistance for 3-wire connection	$\leq$ 11 $\Omega$ per conductor		
Sensor lead resistance	factory-set: 0 $\Omega$ lead resistance		
for 2-wire connection	settable through PC setup program		
Sensor current	≤ 0.5mA		
Sampling rate	continuous measurement because of analog signal path		

### Measurement circuit monitoring to NAMUR recommendation NE43

Underrange	falling to $\leq$ 3.6 mA	
Overrange	rising to $\ge$ 22mA to $<$ 28mA (typically 24mA)	
Probe short-circuit	≤ 3.6mA	
Probe and lead break	positive: $\ge$ 22 mA to $<$ 28mA (typically 24mA) negative: $\le$ 3.6mA	

### Output

Output signal	proportional DC current 4 – 20mA	
Transfer characteristic	linear with temperature	
Transfer accuracy	$\leq \pm 0.1\%$	
Damping of ripple on supply voltage	> 40dB	
Burden (Rb)	Rb = (Ub - 7.5V) / 22mA	
Burden error	$\leq \pm 0.02 \% / 100 \Omega^{1}$	
Settling time on a temperature change	≤ 10msec	
Calibration conditions	24V DC / approx. 22°C	
Calibration/configuration accuracy	$\leq \pm 0.2 \%^{1,2} \text{ or } \leq \pm 0.2 ^{\circ}\text{C}^2$	

### Supply voltage

Supply voltage (Ub)	7.5 – 30V DC
Reverse polarity protection	yes
Supply voltage error	$\leq$ ± 0.01 % per V deviation from 24V <sup>1</sup>

<sup>1</sup> All details refer to the range-end value 20mA <sup>2</sup> The larger value applies

#### Ambient conditions

	dTRANS T03 J Type 707030/	dTRANS T03 B Type 707031/	dTRANS T03 T Type 707032/	
Operating temperature range	-40 to +85°C	-40 to +85°C	-25 to +70°C	
Storage temperature range	-40 to +100°C			
Temperature error	$\leq \pm 0.01$ % per °C deviation from 22 °C <sup>1</sup>			
Climatic conditions	c conditions rel. humidity ≤ 95% annເ		ndensation	
Vibration strength	to GL Characteristic 2 to GL Characteristic 2		-	
EMC - interference emission - immunity to interference	EN 61 326 Class B to industrial requirements			
IP enclosure protection - in terminal head / open mounting - on C-rail	IP54 / IP00 -	IP54 / IP00 -	- IP20	


<sup>1</sup> All details refer to the range-end value 20mA

### Housing


-			
	Type 707030/	Type 707031/	Type 707032/
Material	polycarbonate (encapsulated)	polycarbonate (encapsulated)	polycarbonate
Screw terminal	≤ 1.5mm²; max. torque 0.15Nm	≤ 1.75mm²; max. torque 0.6Nm	≤ 2.5 mm²; max. torque 0.6Nm
Mounting	inside terminal head Form J inside terminal head Form B on DIN 43 729; 35 mm x 7.5 in surface-mounting case on (on request); 15 mm (		on C-rail 35mm x 7.5mm (EN 50 022); on C-rail 15mm (EN 50 045); on G-rail (EN 50 035)
use only or		nly original accessories for mounting!	
Operating position	unrestricted		
Weight	approx. 12g	approx. 45g	approx. 70g

### System diagrams for 2-wire transmitter

### Connection example with supply unit



### Connection example with supply isolator



# Technical data for 3-wire transmitter (Types 707033/..., and 707034/...)

### Input for resistance thermometer

	dTRANS T03 BU Type 707033/	dTRANS T03 TU Type 707034/	
Measurement input	Pt100 (EN 60 751)		
Range limits	-200 to +850°C		
Connection circuit	2-/3-v	vire circuit	
Smallest span	2	25°C	
Largest span	10	050°C	
Unit	°C or °F		
Zero shift	for spans < 75°C fixed zero: -40°C, -20°C, 0°C, 20°C, 40°C		
	for span 75°C: ±50°C		
	for spans > 75°C: see "Range organization" on page 7		
Sensor lead resistance for 3-wire connection	$\leq 11\Omega$ per conductor		
Sensor lead resistance for 2-wire connection	factory-set: 0 $\Omega$ lead resistance, settable through PC setup program		
Sensor current	≤ 0.5mA		
Sampling rate	continuous measurement because of analog signal path		

### Measurement circuit monitoring to NAMUR recommendation NE43

Underrange	0V	
Overrange	rising to > 11V to < 14V (typically 12V)	
Probe short-circuit	0V	
Probe and lead break	positive: rising to > 11V to < 14V (typically 12V) negative: 0V	

### Output

Output signal	DC voltage 0 – 10V	
Transfer characteristic linear with temperature		
Transfer accuracy	$\leq \pm 0.2\%$	
Damping of ripple on supply voltage	> 40 dB	
Load	≥ 10kΩ	
Load error	$\leq \pm 0.1\%$	
Settling time on a temperature change	≤ 10msec	
Calibration conditions	24V DC / approx. 22°C	
Calibration/configuration accuracy	$\le \pm 0.2\%^{1.2} \text{ or } \le \pm 0.2^{\circ} \text{C}^2$	

### Supply voltage

Supply voltage (Ub)	15 – 30V DC	
Reverse polarity protection	yes	
Supply voltage error	$\leq$ ± 0.01 % per V deviation from 24V <sup>1</sup>	

<sup>1</sup> All details refer to the range-end value 10V <sup>2</sup> The larger value applies

#### Ambient conditions

	dTRANS T03 BU Type 707033/	dTRANS T03 TU Type 707034/	
Operating temperature range	-40 to +85°C	-25 to +70°C	
Storage temperature range	-40 to +100°C		
Temperature error	≤ ± 0.01 % per °C	deviation from 22 °C <sup>1</sup>	
Climatic conditions	rel. humidity $\leq$ 95% annual mean, no condensation		
Vibration strength	to GL Characteristic 2	-	
EMC - interference emission - immunity to interference	C	61 326 lass B al requirements	
IP enclosure protection - in terminal head / open mounting - on C-rail	IP54 / IP00 -	- IP20	


<sup>1</sup> All details refer to the range-end value 10V

### Housing

	Туре 707033/	Type 707034/		
Material	polycarbonate (encapsulated)	polycarbonate		
Screw terminal	≤ 1.75mm²; max. torque 0.6Nm	≤ 2.5mm²; max. torque 0.6Nm		
Mounting	inside terminal head Form B DIN 43 729; in surface-mounting case (on request); in switch cabinet (fixing bracket is required)	on C-rail 35mm x 7.5mm (EN 50 022); on C-rail 15mm (EN 50 045); on G-rail (EN 50 035)		
Operating position	use only original accessories for mounting!			
Weight	approx. 45g approx. 70g			

### System diagram for 3-wire transmitter

**Connection example** 



# Setup program (for all types)

The setup program is available for calibrating/configuring the transmitter from a PC.

Connection is through a PC interface (including power supply and adapter) and the setup interface of the transmitter. In order to calibrate/ configure the transmitter, it has to be connected to the supply voltage. If no power supply or supply isolator is available, Types 707030/ ..., 707031/... and 707032/... can be supplied from a 9V block battery.

### Adjustable/configurable parameters

- TAG number (8 characters)
- response to probe and cable break
- range start, range end
- lead resistance for 2-wire circuit

### **Fine calibration**


Fine calibration means adjustment of the output signal of a calibrated/configured transmitter. Errors due to the system (such as an unfavorable probe installation) can be compensated. The signal can be adjusted in the range  $\pm 0.2$  mA for current output and  $\pm 0.1$  V for voltage output. Negative output voltages are not possible with voltage output. Fine calibration can only be carried out through the setup program.

### Hardware and software requirements


The following hardware and software requirements have to be met for installing and operating the setup program:

- IBM-PC or compatible PC from 486DX-2-100
- 64 MB main memory
- 10MB available on hard disk
- CD-ROM drive
- 1 free serial interface
- Win 98, ME or Win NT4.0, 2000, XP

### Connection layout for calibrating/configuring the dTRANS T03 B and BU



### **Range organization**



All the possible range-start values in relation to the range span are contained within the gray area.

#### range span = range end - range start

Example:	range start = -50°C, range end = 250°C range span = range end – range start = 250°C - (-50°C) = 300°C
	Caution: When selecting the range start, make sure it lies within the gray area.
Please note:	for spans smaller than 75 °C, the only permissible start values are: -40 °C, -20 °C, 0 °C, +20 °C and +40 °C.

# **Connection diagram for 2-wire transmitter**

### dTRANS T03 J - Type 707030/...

	Connection for		Terminal assignments		
	$ \stackrel{\clubsuit}{\rightarrow} \stackrel{\bullet}{\rightarrow} $	Supply voltage 7.5 — 30V DC Current output 4 — 20mA	+1 -2	$R_{B} = \frac{U_{b} - 7.5V}{22mA}$ $R_{B} = \text{ burden resistance}$ $U_{b} = \text{ supply voltage}$	1 2 0 0     + -
	Analog input	S		<u> </u>	
Setup	$\Rightarrow$	Resistance thermometer in 2-wire circuit	3 4	standard is $R_L = 0\Omega$	

### dTRANS T03 B - Type 707031/...

	Connection f	for	Terr	ninal assignments	
Setup	$ \stackrel{\frown}{\rightarrow} $	Supply voltage 7.5 — 30V DC Current output 4 — 20mA	+1 -2	$R_{B} = \frac{U_{b} - 7.5V}{22mA}$ $R_{B} = \text{ burden resistance}$ $U_{b} = \text{ supply voltage}$	1 2     + <u>-</u>
	Analog inputs				
		Resistance thermometer in 2-wire circuit	3 5 6	standard is $R_L = 0\Omega$	3 5 6 tt
	$\rightarrow$	Resistance thermometer in 3-wire circuit	3 5 6	$R_L \le 11\Omega$ $R_L$ = lead resistance per conductor	

### dTRANS T03 T - Type 707032/...

	Connection	for	Terr	ninal assignments	
	$ \stackrel{\clubsuit}{\rightarrow} $	Supply voltage 7.5 — 30V DC Current output 4 — 20mA	+81 -82	$R_{B} = \frac{U_{b} - 7.5V}{22mA}$ $R_{B} = \text{ burden resistance}$ $U_{b} = \text{ supply voltage}$	81 82     + -
	Analog inputs				
G+ 81/82 420mA +81-82		Resistance thermometer in 2-wire circuit	11 12 13	standard is $R_L = 0\Omega$	11 12 13 tt,
		Resistance thermometer in 3-wire circuit	11 12 13	$R_L \le 11\Omega$ $R_L$ = lead resistance per conductor	

## **Connection diagram for 3-wire transmitter**

### dTRANS T03 BU - Type 707033/...

€11/12/13

SETUF

dTRANS

::

⊕ 81/82 ⊕ 82/83

+81-82+83

	Connection	Connection for		Terminal assignments		
Setup o	$\rightarrow$	Supply voltage 15 — 30V DC	+1 -2			
	$\rightarrow$	Voltage output 0 — 10V	-2 +3	$load \geq 10  k\Omega$	+ - +	
	Analog inpu	Analog inputs				
	$\rightarrow$	Resistance thermometer in 2-wire circuit	4 5 6	standard is $R_L = 0\Omega$	4 5 6 tt	
	$ \rightarrow $	Resistance thermometer in 3-wire circuit	4 5 6	$R_L \le 11\Omega$ $R_L = lead resistance$ per conductor		
dTRANS T03 TU - Type 707034/						
	Connection	for	Terr	ninal assignments		
	$\rightarrow$	Supply voltage 15 — 30V DC	+81 -82		81 82 83	

Voltage output

0 - 10V

Resistance

thermometer in

thermometer in


3-wire circuit

2-wire circuit


Resistance

Analog inputs

# Dimensions



#### dTRANS T03 T and dTRANS T03 TU C-rail 35mm x 7.5mm EN 50 022



### dTRANS T03 B and dTRANS T03 BU

 $load \geq 10 k \Omega$ 

 $R_{I} \leq 11 \, \Omega$ 

standard is  $R_L = 0\Omega$ 

R<sub>L</sub> = lead resistance

per conductor

-82

+83

11

12

13

11


12

13



C-rail 15mm EN 50 045

92




11 12 13

13

12

G-rail EN 50 035



### Order details: JUMO dTRANS T03

Analog transmitter with digital adjustment

						(1) Basic version
					707030	dTRANS T03 J analog 2-wire transmitter for installation in terminal head Form J (2-wire circuit only)
					707031	dTRANS T03 B analog 2-wire transmitter for installation in terminal head Form B
					707032	dTRANS T03 T analog 2-wire transmitter for rail mounting
					707033	dTRANS T03 BU analog 3-wire transmitter for installation in terminal head Form B
					707034	dTRANS T03 TU analog 3-wire transmitter for rail mounting
						(2) Basic type extensions
х	х	х	х	х	880	adjustable,
x	x	x	x	x	990	factory-set (probe break: positive; lead resistance: $0\Omega$ ) adjustable,
Â	^	<b> </b> ^	^	^	550	setting to customer specification (please specify in plain text)
х	х	х	х	х	881	configurable,
~	~	~	v	v	991	factory-set (probe break: positive; lead resistance: $0\Omega$ ) configurable.
х	х	х	х	х	991	setting to customer specification (please specify in plain text)
						(3) Input
	х	х	х	х	001	Pt100 in 3-wire circuit
х	х	х	х	х	003	Pt100 in 2-wire circuit
						(4) Output
х	х	х	x	x	005 040	4 — 20mA 0 — 10V
1	I		^	^	040	0 - 100
0	4.0		da		L	(1) (2) (3) (4)
Ord	Jer	co	ue			
Ord	der	ex	am	ple		707031 / 880 - 001 - 005

### **Standard accessories**

- Operating Instructions
- Fixing items

### Accessories

- PC setup program, multilingual
- PC interface cable (isolated) with TTL/RS232 converter, power supply (230V AC) and adapter
- Supply units 1- way and 4-way (Data Sheet 70.7500)
- Isolating amplifier and supply isolator (Data Sheet 70.7510)
- Supply unit for transmitters (Data Sheet 70.7520)
- Fixing bracket for mounting Type 707031/... and Type 707033/... on rail, Sales No. 00352463